

USER MANUAL

Vacuum Mixer



Description

Vacuum mixer is used for mixing and vibrating investment materials and molded materials. As the mixing process is done in a vacuum state, the work piece is free of bubbles, and firmness and compactness of the mold has also been improved.

Specification

Voltage	AC220V±10%
Power	150W
Bowl Capacity	500ml
Gross Weight	27kg
Dimensions	43x43x59cm

Method of Installation

Our vacuum Mixer is a table type machine; it will work normally combined with the air compressor. Unpack the package, then check if all the accessories are inside. Connect the machine to a power supply. Then the machine can be operated following the instruction.

Instruction

- 1.Put oil into the vacuum pump(up to the line). Make sure the oil is within 5mm up or down the oil line while using.
- 2.Connect the power wire of the oil pump with the mixing machine.
- 3.Plug in the machine.
- 4.Stir the material inside the vacuum bowl to pasty state.
- 5.Screw up the air outlet bolt. Switch on the machine and preset the *Mixing* time. Press the *Vacuum Pump* button. Connect the vacuum bowl closely with the machine and then press *Mixing*.
- 6.After finishing the mixing, switch off the machine.
- 7.Use the lower black part to vibrate.

Cautions

- 1.Read all the operation steps before use to avoid damage.
- 2.The oil pump must not be operated without oil in it.
- 3.The oil pump must not be operated without pumping anything.
- 4.Do not disassemble the machine without professional instruction.
- 5.Please check the grounding of the machine regularly. Make sure there is a safe connection between the case of machine and the ground.
- 6.Make sure the investment is **less than one** half of the vacuum bowl in case there is blocking of the air circuit.

Contact Us

E-mail Address:

Dentalsalemall.com@gmail.com

Telephone Number: +86-023-68438829

Official Site:<https://www.dentalsalemall.com>